

USER MANUAL

F-Series Sideshifter

CONTENTS

	Page
INTRODUCTION	
Special Definitions	1
OPERATION	
Safety Rules	2
Industrial Lift Trucks	2
Handling Loads	3
Sideshifter Operation	3
Safe Operation and Maintenance	4
Industrial Trucks and Attachments	4
TRUCK REQUIREMENTS	5
HYDRAULIC SUPPLY	5
INSTALLATION	6
PERIODIC MAINTENANCE	
Daily, 1000 & 2000-Hour Maintenance	9
PARTS	
Recommended Spare Parts	10
Publications	10

Original Instructions

Number 219941-R14 EN



**cascade[®]
corporation**

Cascade is a Registered Trademark of Cascade Corporation

INTRODUCTION

This user manual is for Cascade F-Series Sideshifters. It contains an Operation Guide, Installation Instructions, and Recommended Spare Parts.

IMPORTANT: All hosing and flared fittings on F-Series Sideshifters are JIC as standard, with face seal as an option.

NOTE: All specifications are shown in metric units where applicable. All fasteners have a torque value range $\pm 10\%$ of stated value.

Special Definitions

The statements shown appear throughout this manual where special emphasis is required. Read all WARNINGS and CAUTIONS before proceeding with any work. Statements labeled IMPORTANT and NOTE are provided as additional information of special significance or to make the job easier.



WARNING – A statement preceded by WARNING is information that should be acted upon to prevent **bodily injury**. A WARNING is always inside a ruled box.

CAUTION – A statement preceded by CAUTION is information that should be acted upon to prevent machine damage.

IMPORTANT – A statement preceded by IMPORTANT is information that possesses special significance.

NOTE – A statement preceded by NOTE is information that is handy to know and may make the job easier.



WARNING: Rated capacity of the truck/attachment combination is a responsibility of the original truck manufacturer and may be less than shown on the attachment nameplate. Consult the truck nameplate.


WARNING: Do not operate this attachment unless you are a trained and authorized lift truck driver.

OPERATION

This section contains operating instructions for Cascade F-Series Sideshifters. It will help you avoid common errors which often cause damage to the equipment or product being handled.

This information is intended to simplify operator understanding about effective and safe Sideshifter use and operation. Read this information thoroughly before operating the attachment. Be sure you know and understand all operating procedures and safety precautions. If you have any questions, or don't understand a procedure, ask your supervisor.

Emphasize Safety! Most accidents are caused by operator carelessness or misjudgment. You must watch for poorly maintained equipment and hazardous situations and correct them.



OPERATION

Safety Rules – Industrial Lift Trucks

No riders





No reaching through mast




No standing under load




GA0047.eps



RAMPS




GA0048.eps




OPERATION

Safety Rules – Handling Loads



CAUTION: Do not put side loads on forks.




Center load prior to traveling and hoisting.

Raise load prior to sidsifting.


Limit mast tilting with raised load.




Limit sidsifting with raised load.



Limit truck movement with raised load.



Top of load should not extend above backrest.




FP2383.eps

Load weight must not exceed combined truck/attachment capacity (see truck nameplate).

Total fork capacity (LH + RH fork) must be greater than load weight. Check capacity stamp on forks.

Sidesifter Operation


AUXILIARY VALVE FUNCTIONS



GA0010.eps

SIDESHIFTING

- A Sideshift Left
- B Sideshift Right



SS0160.eps



WARNING: Truck control handle and attachment function activation shown here conforms to ISO 3691 ANSI/ITSDF B56.1 recommended practices. Failure to follow these practices may lead to serious bodily injury or property damage. End user, dealer and OEMs should review any deviation from the practices for safe operation.

SAFE OPERATION AND MAINTENANCE

Industrial Trucks and Attachments



WARNING: When operating and maintaining industrial trucks equipped with attachments, you should pay particular attention to the following information. You should be familiar with this information for truck and attachment operation. **Ask your employer for complete operation information.**

General Requirement

Modifications and additions which affect capacity and safe operation shall not be performed by the customer or user without manufacturers prior written approval. Capacity, operation and maintenance instruction plates, tags or decals shall be changed accordingly.

If the truck is equipped with front-end attachments other than factory installed attachments, the user shall request that the truck be marked to identify the attachments and show the appropriate weight of the truck and attachment combination at maximum elevation with load laterally centered.

The user shall see that all nameplates and markings are in place and maintained in a legible condition.

Safety Guards

If the type of load presents a hazard, the user shall equip fork trucks with a vertical load backrest extension in accordance with the following.

All new powered industrial trucks acquired and used by an employer after February 15, 1972 shall meet the design and construction requirements for powered industrial trucks established in the "American National Standard for Powered Industrial Trucks, Part II, ANSI B56.1", except for vehicles intended primarily for earth moving or over-the-road hauling.

Operator Training

Only trained and authorized operators shall be permitted to operate a powered industrial truck. Methods shall be devised to train operators in the safe operation of powered industrial trucks.

Truck Operations

Trucks shall not be driven up to anyone standing in front of a bench or other fixed object.

No person shall be allowed to stand or pass under the elevated portion of any truck, whether loaded or empty.

Unauthorized personnel shall not be permitted to ride on powered industrial trucks. A safe place to ride shall be provided where riding of trucks is authorized.

The employer shall prohibit arms or legs from being placed between the uprights of the mast or outside the running lines of the truck.

When a powered industrial truck is left unattended, load engaging means shall be fully lowered, controls shall be neutralized, power shall be shut off and brakes set. Wheels shall be blocked if the truck is parked on an incline.

A powered industrial truck is unattended when the operator is 7 meter or more away from the vehicle which remains in his view, or whenever the operator leaves the vehicle and it is not in his view.

When the operator of an industrial truck is dismounted and within 7 meter of the truck still in his view, the load engaging means shall be fully lowered, controls neutralized and the brakes set to prevent movement.

A safe distance shall be maintained from the edge of ramps or platforms while on any elevated dock or platform or freight car. Trucks shall not be used for opening or closing freight doors.

A load backrest extension shall be used whenever necessary to minimize the possibility of the load or part of it from falling rearward.

Traveling

The driver shall be required to slow down and sound the horn at cross isles and other locations where vision is obstructed. If the load being carried obstructs forward view, the driver shall be required to travel with the load trailing.

When ascending or descending grades in excess of 10 percent, loaded trucks shall be driven with the load upgrade.

On all grades the load and load engaging means shall be tilted back if applicable, and raised only as far as necessary to clear the road surface.

Loading

Only stable or safely arranged loads shall be handled. Caution shall be exercised when handling off-center loads which cannot be centered.

Only loads within the rated capacity of the truck shall be handled.

The long or high (including multiple-tiered) loads which may affect capacity shall be adjusted.

Trucks equipped with attachments shall be operated as partially loaded trucks when not handling a load.

A load engaging means shall be placed under the load as far as possible; the mast shall be carefully tilted backward to stabilize the load.

Extreme care shall be used when tilting the load forward or backward, particularly when high tiering. Tilting forward with load engaging means elevated shall be prohibited except to pick up a load. An elevated load shall not be tilted forward except when the load is in a deposit position over a rack or stack. When stacking or tiering, only enough backward tilt to stabilize the load shall be used.

Operation of the Truck

If at any time a powered industrial truck is found to be in need of repair, defective, or in any way unsafe, the truck shall be taken out of service until it has been restored to safe operating condition.

Maintenance of Industrial Trucks

Any power-operated industrial truck not in safe operating condition shall be removed from service. All repairs shall be made by authorized personnel.

All parts of any such industrial truck requiring replacement shall be replaced only by parts equivalent as to safety with those used in the original design.

Industrial trucks shall not be altered so that the relative positions of the various parts are different from what they were when originally received from the manufacturer, nor shall they be altered either by the addition of extra parts not provided by the manufacturer or by the elimination of any parts. Additional counter-weighting of fork trucks shall not be done unless approved by the truck manufacturer.

Industrial trucks shall be examined before being placed in service and shall not be placed in service if the examination shows any condition adversely affecting the safety of the vehicle. Such examinations shall be made at least daily. When industrial trucks are used on a round-the-clock basis, they shall be examined after each shift. Defects when found shall be immediately reported and corrected.

TRUCK REQUIREMENTS



Truck Relief Setting

Iron Lower Hooks and Composite Bearings	Bronze Upper and Lower Bearings	
140 bar	180 bar	Recommended Maximum
240 bar	240 bar	

Truck Flow Volume ^①

	Min. ^②	Recommended	Max. ^③
55F, 65F	4 l/min	7.5 l/min	11 l/min
100F, 120F, 150F, 165F	4 l/min	15 l/min	19 l/min

- ① Cascade F-Series Sideshifters are compatible with SAE 10W petroleum base hydraulic fluid meeting Mil. Spec. MIL-O-5606 or MIL-O-2104B. Use of synthetic or aqueous base hydraulic fluid is not recommended. If fire resistant hydraulic fluid is required, special seals must be used. Contact Cascade.
- ② Flow less than recommended will result in a slow sideshift speed.
- ③ Flow greater than maximum can result in excessive heating, reduced system performance and short hydraulic system life.




Carriage Mount Dimension (A) ISO

	Minimum	Maximum
Class II	380.0 mm	381.0 mm
Class III	474.5 mm	476.0 mm
Class IV	595.5 mm	597.0 mm

Carriage – Clean and inspect carriage bars. Make sure that bars are parallel and ends are flush. Grind smooth any protruding welds that may affect Sideshifter lower bearings. Repair any damaged notches.

HYDRAULIC SUPPLY

The Sideshifter will require one of the hydraulic supply arrangements shown below. All hoses and fittings should be at least No. 4 with 5 mm minimum ID. Refer to Cascade *Hose & Cable Reel Selection Guide*, Part No. 212199 to select the correct hose reel for the mast and truck.




- A** RH THINLINE™ 2-Port Hose Reel Supply Group
OR
B Mast Single Internal Hose Reeving




WARNING: Truck control handle and attachment function activation shown here conforms to ISO 3691 ANSI/ITSDF B56.1 recommended practices. Failure to follow these practices may lead to serious bodily injury or property damage. End user, dealer and OEMs should review any deviation from the practices for safe operation.

Auxiliary Valve Functions




INSTALLATION



1 Attach overhead hoist




2 Remove bolt-on lower hook(s)



Two Capscrew Hooks




Wide Lower Hook



Four Capscrew Hooks *


* No longer in production.

3 Mount Sideshifter on truck carriage




4 Install lower hooks

BOLT-ON HOOKS – Two Capscrew




WIDE LOWER HOOK




NOTE: If frame is equipped with a hydraulic component guard, remove the guard to access shims located on the lower fork bar.

QUICK-DISCONNECT HOOKS




BOLT-ON HOOKS – Four Capscrew




NOTE: If frame is equipped with a hydraulic component guard, remove the guard to access shims located on the lower fork bar.

INSTALLATION

5 Flush supply hoses




6 Install hoses




7 Install forks



WARNING: If the fork locking pin is not fully engaged, the fork could become disengaged from the carriage.




8 Install backrest



9 Lubricate lower bearings

Lubricate lower bearings with general-purpose chassis grease.

NOTE: Upper bearings are prelubed at the Factory with break-in grease. No lubrication is required during installation.



PERIODIC MAINTENANCE

Daily

Check items shown each day. Report problems to your supervisor. See Service Manual for troubleshooting, maintenance and repair procedures.



WARNING: If the fork locking pin is not fully engaged, the fork could become disengaged from the carriage.



WARNING: After completing any service procedure, always test the sideshifter through five complete cycles. First test with no load, then test with a load to make sure the attachment operates correctly before returning it to the job.

1000-Hour

Every time the lift truck is serviced or every 1000 hours of truck operation, complete the following maintenance procedures:

- Check for loose or missing fasteners, worn or damaged hoses, hydraulic leaks and damaged or missing fork stops.
- Inspect lower hooks for wear and proper clearance. Adjust if necessary, refer to Installation, step 4. Tighten lower hook capscrews to:

Two Capscrew Hooks

Class II/III – 165 Nm

Class IV – 320 Nm


Wide Lower Hook & Four Capscrew Hooks

Class II – 90 Nm

Class III – 225 Nm

Class IV – 435 Nm

- Inspect upper and lower bearings for wear. If any bearing is worn to less than 2.5 mm thickness, replace the entire bearing set. Refer to service manual for replacement procedure.
- Tighten backrest capscrews (Cascade) to 195 Nm.
- Apply general-purpose chassis grease to Sideshifter upper and lower bearings.



2000-Hour

After 2000 hours of truck operation, in addition to the Daily and 1000-hour maintenance, forks in use shall be inspected at intervals of not more than 12 months (for single shift operations) or whenever any defect or permanent deformation is detected. Severe applications will require more frequent inspection.

Fork inspection shall be carried out by trained personnel to detect any damage that might impair safe use. Any fork that is defective shall be removed from service. Reference ANSI B56.1-2005.

Inspect for the following defects:

- Surface cracks
- Straightness of blade and shank
- Fork angle
- Difference in height of fork tips
- Positioning lock
- Wear on fork blade and shank
- Wear on fork hooks
- Legibility of marking

NOTE: Fork Safety Kit 3014162 contains wear calipers, inspection sheets and safety poster. Also available is fork hook & carriage wear gauge 209560 (Class II), 209561 (Class III) and 6105257 (Class IV).

Recommended Spare Parts

55F PART NO.	65F PART NO.	100F PART NO.	120F, 150F, 165F PART NO.	DESCRIPTION	UNITS SERVICED		
					1-5	6-19	20-50
					QTY.	QTY.	QTY.
228782 ♦	6051249	6051249	6079936	Upper Bearing–Composite	8	16	32
6000616 ♦	6052405	6052405	6082297	Upper Bearing–Bronze	4	8	16
6000914 ♦	6057162	6057162	6057162	Lower Bearing–Composite	6	12	24
225570 ♦	6058041	6058041	6058041	Lower Bearing–Bronze	4	8	16
6827696	6878699	6878699	6898535	Lower Bearing ▲ (WLH)	4	8	16
■	■	■	—	Lower Hook ▲ (WLH)	2	8	16
204186	204186	204186	6083157	Lower Hook	0	2	4
6818778	—	—	—	Lower Hook ●	0	2	4
6818788	—	—	—	Lower Hook Bearing–Bronze ●	4	8	16
6818771	—	—	—	Lower Hook Bearing Shim ●	6	12	24
681473	—	—	—	Lockwasher, M12 ●	0	8	16
678991	—	—	—	Lockwasher, M12 ▲ (WLH)	0	8	16
—	678992	678992	—	Lockwasher, M16 ▲ (WLH)	0	8	16
—	—	—	681469	Lockwasher, M20 ▲ (WLH)	0	8	16
206174	—	—	—	Capscrew, M12 x 45 ●	0	8	16
752903	752903	752903	—	Capscrew, M16 x 45	0	4	8
—	—	—	768580	Capscrew, M20 x 60	0	4	8
766929	—	—	—	Capscrew, M12 x 40 ▲ (WLH)	8	12	16
—	767810	767810	—	Capscrew, M16 x 45 ▲ (WLH)	8	12	16
—	—	—	769582	Capscrew, M20 x 50 ▲ (WLH)	8	12	16
678990	678990	678990	—	Nut, M16	0	4	8
—	—	—	783800	Nut, M20	0	4	8
667225	667225	667225	215419	Washer	0	4	8
■	■	■	■	Cylinder Assembly	0	0	1
219868	219868	6091229	6091229	Cylinder Service Kit	1	2	4

♦ Match the bearing being replaced. For units built prior to 2004, refer to Technical Bulletins TB 261 for upper bearings and TB 272 for lower bearings.


■ Refer to part number stamped on part or supply serial number stamped on sidershifter frame when purchasing parts.

● Four Capscrew Hook applications.

▲ Wide Lower Hook (WLH) applications.

Publications

PART NO.	DESCRIPTION
219941	User Manual
220526	Service Manual
679929	Tool Catalog



GA0377.eps

Do you have questions you need answered right now? Call your nearest Cascade Service Department. Visit us online at www.cascorp.com

Zijn er vragen waarop u direct een antwoord nodig hebt? Neem dan contact op met uw dichtstbijzijnde serviceafdeling van Cascade. Of ga naar www.cascorp.com

Haben Sie Fragen, für die Sie sofort eine Antwort benötigen? Wenden Sie sich an Ihren nächsten Cascade-Kundendienst. Besuchen Sie uns online: www.cascorp.com

En cas de questions urgentes, contacter le service d'entretien Cascade le plus proche. Visiter le site Web www.cascorp.com.

Per domande urgenti contattare l'Ufficio Assistenza Cascade più vicino. Visitate il nostro sito all'indirizzo www.cascorp.com

¿Tiene alguna consulta que deba ser respondida de inmediato? Llame por teléfono al servicio técnico de Cascade más cercano. Visítenos en www.cascorp.com

AMERICAS

**Cascade Corporation
U.S. Headquarters**
2201 NE 201st
Fairview, OR 97024-9718
Tel: 800-CASCADE (227-2233)
Fax: 888-329-8207

Cascade Canada Inc.
5570 Timberlea Blvd.
Mississauga, Ontario
Canada L4W-4M6
Tel: 905-629-7777
Fax: 905-629-7785

Cascade do Brasil
Praça Salvador Rosa,
131/141-Jordanópolis,
São Bernardo do Campo - SP
CEP 09891-430
Tel: 55-13-2105-8800
Fax: 55-13-2105-8899

EUROPE-AFRICA

**Cascade Italia S.R.L.
European Headquarters**
Via Dell'Artigianato 1
37030 Vago di Lavagno (VR)
Italy
Tel: 39-045-8989111
Fax: 39-045-8989160

Cascade (Africa) Pty. Ltd.
PO Box 625, Isando 1600
60A Steel Road
Sparton, Kempton Park
South Africa
Tel: 27-11-975-9240
Fax: 27-11-394-1147

ASIA-PACIFIC

Cascade Japan Ltd.
2-23, 2-Chome,
Kukuchi Nishimachi
Amagasaki, Hyogo
Japan, 661-0978
Tel: 81-6-6420-9771
Fax: 81-6-6420-9777

Cascade Korea
121B 9L Namdong Ind.
Complex, 691-8 Gojan-Dong
Namdong-Ku
Inchon, Korea
Tel: +82-32-821-2051
Fax: +82-32-821-2055

Cascade-Xiamen
No. 668 Yangguang Rd.
Xinyang Industrial Zone
Haicang, Xiamen City
Fujian Province
P.R. China 361026
Tel: 86-592-651-2500
Fax: 86-592-651-2571

**Cascade India Material
Handling P Ltd**
Sy no 271/8, Ingawale Patil
Estate,
Godown No.9,10 & 11, Bhugaon,
Off Paud Road, Tal Mulshi, Dist
Pune 411 042

Cascade Australia Pty. Ltd.
1445 Ipswich Road
Rocklea, QLD 4107
Australia
Tel: 1-800-227-223
Fax: +61 7 3373-7333

Cascade New Zealand
15 Ra Ora Drive
East Tamaki, Auckland
New Zealand
Tel: +64-9-273-9136
Fax: +64-9-273-9137

**Sunstream Industries
Pte. Ltd.**
18 Tuas South Street 5
Singapore 637796
Tel: +65-6795-7555
Fax: +65-6863-1368

