




Installation Instructions

Fork Positioner Pallet Guard Kit 6859144

This sheet provides instructions on how to install a Pallet Guard on Cascade 70K Fork Positioners to protect pallets from fork damage. The kit includes a Pallet Guard and mounting hardware.

- 1** Determine if the unit needs to have a lower mounting tab installed. A tab is included in the kit if needed. If required to install the tab:
 - Assemble the pallet guard and lower tab to the fork positioner to establish the lower tab location. Mark the location.
 - Remove the pallet guard. Weld the tab using AWS E70T-1 1/16 in. (1.6 mm) or 5/64 in. (2 mm) diameter wire with 100% CO₂ shielding gas at 35-50 CFH. Weld using .25 in. (5 mm) skip welds, 1 in. (25 mm) long.
 - Remove slag from weld. Apply paint to weld areas.
- 2** Install the Pallet Guard using the supplied capscrews, lockwashers and washers. Tighten the capscrews to a torque of 50 ft.-lbs. (65 Nm).



cascade®
corporation

For Technical Support . . .

Call: 1-800-227-2233 Fax: 1-888-329-8207

Internet: www.cascorp.com

Write: Cascade Corporation, PO Box 20187, Portland, OR 97294

© Cascade Corporation 2014

To Order Parts . . .

Call: 1-888-227-2233 Fax: 1-888-329-0234

Internet: www.cascorp.com

Write: Cascade Corporation, 2501 Sheridan Ave., Springfield, OH 45505

Part No. 6859145

12-2014